

Application Techniques for Installation

APPLICATION:		STAPLE/NAIL			STAPLE/NAIL W/PGD			FULL GLUE DOWN					
SUBSTRATE:		PLYWOOD									CONCRETE		
LOCATION:		ABOVE GRADE	BELOW GRADE	ON GRADE	ABOVE GRADE	BELOW GRADE	ON GRADE	ABOVE GRADE	BELOW GRADE	ON GRADE	ABOVE GRADE	BELOW GRADE	ON GRADE
Castillo Plank <i>Engineered</i>	6"	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	7"				✓	✓	✓	✓	✓	✓	✓	✓	✓
	8"				✓	✓	✓	✓	✓	✓	✓	✓	✓
Estate Plank <i>Engineered</i>	6"	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
	7"				✓	✓	✓	✓	✓	✓	✓	✓	✓
	8" - 8½"				✓	✓	✓	✓	✓	✓	✓	✓	✓
Cascadia <i>Engineered</i>	8"				✓	✓	✓	✓	✓	✓	✓	✓	✓
Reclaimed <i>Engineered</i>	7"				✓	✓	✓	✓	✓	✓	✓	✓	✓
	8½"				✓	✓	✓	✓	✓	✓	✓	✓	✓
<i>Engineered Alder: Antique Alder & Belleville Plank</i>	7"				✓	✓	✓	✓	✓	✓	✓	✓	✓
<i>Solid Alder: Antique Alder & Belleville Plank</i>	4¼"	✓		✓	✓		✓	✓		✓	✓		
	6"	✓		✓	✓		✓	✓		✓	✓		

Note: All *Antique Impressions Engineered Flooring* can be installed over in-floor heating systems. Please follow the *Creative At Home* and *NWFA* installation guidelines. Please submit the Homeowner Responsibility Form prior to installation.

Note: For ALL *Antique Impressions Flooring* products, we recommend gluing the end butt joints with Tongue & Groove adhesive applied to the bottom of the groove, for optimal performance.

UPDATED: NOV 25, 2015



8028 Enterprise Street Burnaby, BC, Canada V5A 1V7
Tel: 604-692-2555 • Toll Free: 1-877-828-1888
Fax: 604-692-2556 • Email: info@creativeathome.com

